

PRODUCT ASSEMBLY INSTRUCTIONS • Item #: Depot-006-B/Depot-022-B SQUARE CAN DOG WASTE STATIONS

Depot-006-B/Depot-022-B DOG WASTE STATION

PARTS LIST:

- Can (1)
- Post (1)
- Dispenser (1)
- Sign (1)
- Spacer (1)
- Hardware Pack (1)
- Dispenser Keys (2) *INSIDE Dispenser
- 400 Bags
- 50 Can Liners



CAN (1)



Can Clamps
Hold Bag In-place



DISPENSER (1)
(Roll Bag or ONEPul®)



POST* (1)

*2 Post Sections 47 1/2" Each



HARDWARE (1)



SIGN (1)








400 WASTE BAGS



50 CAN LINERS

NUTS & BOLTS LIST:

- 3" Bolt (6)
- A** 
- 1 1/2" Bolt (2)
- B** 
- Flat Washer (8)
- C** 
- Split-Lock Washer (8)
- D** 
- Hex Nuts (8)
- E** 

Item #: Depot-006-B/Depot-022-B DOG WASTE STATION ASSEMBLY INSTRUCTIONS

1. **ASSEMBLE POST:** Overlap post one 4" onto post two. Thread 2 bolts (B) with 2 flat washers (C) to connect. Tighten with nuts and lock washers (D, E).
2. **MARK ASSEMBLED POST** 14" from tapered end: bury the post in concrete level to 14" mark.
3. **ATTACH CAN:** Install 5" above ground; thread the 2 bolts (A) with 2 flat washers (C) through the can from the inside. Line up the bolts with holes in the post and tighten with nuts and lock washers (D, E).
Note: place "Spacer" between the can and the post to level can. (the gap created by post overlap).
4. **ATTACH DISPENSER:** Line up dispenser 12" ABOVE the top of the can. Thread bolts from the inside of the dispenser. Be sure to put **FLAT WASHERS** on each bolt before threading bolts through the dispenser. Secure to post with nuts and washers.
5. **ATTACH SIGN** to top of post with 2 bolts, nuts and washers (use 2 A, C, D, E).
6. **FILL DISPENSER** with bags – Install Can Liner.

PLEASE BE SURE TO TIGHTEN ALL NUTS AND BOLTS SECURELY



Depot-006-B/Depot-022-B

